

PIG® Acid Neutralising Spill Kit

KIT318-999 Absorbs up to 15.7 L, 1 each

Don't make an acid-based spill worse by responding with a spill kit that's not up to the challenge. Make sure you're prepared with this PIG® Spill Kit, which both neutralises and absorbs acids.

- All absorbents in this specially-designed Kit both neutralise and soak up acidic spills; cleanups are more complete and safer
- Use Socks to confine spill before it can spread; use Mats, Pillows and Ampho-Mag™ Neutraliser to soak up spill
- Contents are organised for quick, efficient response
- 100% polyethylene container is light weight, portable and chemical-resistant; moulded-in handles ensure a firm grip when carrying
- Weather-proof polypropylene lid is hinged for easy access; keeps Kit contents clean and dry prior to use, indoors or out
- Large, colour-coded label makes identification fast and accurate during an emergency
- Tamper-proof seal protects Kit against pilfering of spill-response supplies



Specifications

Dimensions	34cm W x 41.5cm L x 47.5cm H
Fluids Absorbed	Acids
Absorbency	Up to 15.7 L
Lift-Out Basket	No Lift-Out Basket
Outdoor Storage	Can Be Stored Outdoors
Sold as	1 each
Weight	9.1 kg
# per Pallet	24
Composition	Absorbents - Magnesium Sulfate, Sodium Carbonate & Other Neutralising Agents; Loose - Amphoteric Material; Disposal Bags - Polyethylene; Container - HDPE
Includes	2 - 5cm x 122cm Acid Neutralising Socks (PIG309)

5 - 30cm x 30cm Acid Encapsulating/Neutralising Mats (MAT304)
2 - 30cm x 30cm Acid Neutralising Pillows
2 - 1.4kg Ampho-Mag™ Neutraliser Shaker Bottles (PLP217)
2 - 46cm x 76cm Polyethylene Disposal Bags (BAG201-S)

Spill Volume	Under 25 ltr.
UV Resistant	Not UV Resistant
Wheels	No Wheels

Technical Documents

[Acid Neutralising Guidelines](#)

[Treatment Ratios for PIG Neutralising Absorbents](#)

[Ampho-Mag Neutraliser](#)

[PIG Acid Encapsulating / Neutralising Absorbents](#)

Disclaimers

[HazMat/Chemical Notice](#)

To ensure effectiveness and your safety, we recommend that you conduct compatibility and absorption testing of your chemicals with PIG® HazMat Chemical products and PIG® Essentials Chemical products prior to purchase. If you have any questions or need samples to test, please call Technical Services.

[Hydrofluoric Acid Notice](#)

Not for use with hydrofluoric acid.



Hogs Hill • Watt Place • Hamilton International Technology Park • Blantyre • Glasgow • G72 0AH
0800 919 900 • newpig.co.uk • pigpen@newpig.com